

Soffit Slab Installation Guide

It is advisable to start with a focus reference slab in the centre of the soffit when fixing a tile or modular system with subsequent slabs being fixed working towards each edge. The use of laser alignment will assist ensuring alignment and squareness of installation.

Recommended mechanical fixings:

Soffit Slabs should be fixed direct to the concrete soffit using Ejot DDS fixings with the Ejot DDT70 washer or similar. Recommended number and pattern of fixings for each slab size are shown in figures 1 and 2 below. Care should be taken not to over-tighten fixings to prevent damage to slab surface. For further information on fixing type and suitability, please refer to the fixing manufacturer.

	Plain, Foil & Tissue Faced Soffit Slab		
Thickness	130mm	145mm	160mm
EJOT ® Fixing	DDS 7.3 x 175mm	DDS 7.3 x 175mm	DDS 7.3 x 200mm
EJOT Washer	DDT 70mm		

DDT 70



DDS 7.3



DISCLAIMER

The information given in this brochure is believed to be accurate at the time of publication, therefore Terra Building Materials LTD. does not accept legal responsibility for the contents of this catalogue. Unless otherwise specifically stated, product specifications mentioned in this brochure were current at the time of writing and are subject to change without notice by the manufacturers or distributors. Terra Building Materials LTD. does not accept legal responsibility for consequences of applying the product different then described within this brochure. Any dissemination, distribution, copying or use of this catalogue is strictly prohibited. All rights reserved in this catalogue cannot be replicated or used without Terra Building Materials LTD.'s consent. Before you print think about the ENVIRONMENT.

